

0000A0A5071

**SERVICE MANUAL**

MARINE DIESEL ENGINE

6CX-GTYE

---

2000. 3. 10

# FOREWORD

This service manual outlines procedures for servicing and maintaining Yanmar 6CX–GTYE engines to obtain maximum life and performance. It explains about the structure, performance, dis– and re–assembly procedures, important inspection points, servicing instructions and the wear limit of parts. For a full understanding of this manual, also refer to the Operation Manual and Parts Catalog. Besides reference use at your service shop, this manual can also be used as a text for your service engineers. You should understand the contents of this manual fully to offer accurate and efficient service to your customers.

For accurate and efficient work, the following preparations are necessary:

1. Check the service date of your customer

- ① When was the last service?
- ② How many months or hours has the engine been used since the last service?
- ③ What was the trouble and what parts were replaced in the last service?
- ④ What parts must be replaced in the present service?

2. Preparation of Parts

Check the inventory of parts that are necessary for servicing.

3. Preparation of Report Forms

Inspection and service check sheets, parts measurement record form, operation test record form.

# CONTENTS

<b>1. Specifications</b>	1
1-1. Major Specification	1
<b>2. Disassembly and Reassembly</b>	3
2-1. Preparations before Disassembly and Reassembly	3
2-2. Disassembly and Reassembly Tools	4
2-3. Reassembly Procedures	9
<b>3. Inspection and Servicing of Major Engine Parts</b>	31
3-1. Cylinder Head	31
3-2. Piston and Piston Pin	36
3-3. Connecting Rod	40
3-4. Cylinder Sleeve	41
3-5. Cylinder Block	43
3-6. Crankshaft and Main Bearing	43
3-7. Camshaft and Valve Gear	48
3-8. Timing Gear	50
3-9. Lube Oil System	51
3-10. Cooling Water System	55
3-11. Fuel Oil System	59
3-12. Piping Diagram	74
3-13. Electrical Equipment	78
3-14. Reduction Reversing Gears	87
3-15. Turbocharger	98
3-16. Front Driving Equipment	112
<b>4. Periodic Inspection</b>	113
<b>5. Service Standard</b>	115
<b>6. Adjustment and Set Values</b>	117
<b>7. Tightening Torque of Major Bolts and Nuts</b>	118

# 1. Specification

## 1-1. Major Specification









ENGINE MODEL		UNIT	6CX-GTYE			
Type			Vertical, water-cooling, 4-cycle diesel engine			
Combustion system			Direct in jection			
Aspiration			Turbocharger with air cooler			
No. of cyl. - bore×Stroke		mm	6-110×130			
Displacement		ℓ	7.413			
Rated out put		kW(HP)/rpm	265(360)/2600			
Max out put		kW(HP)/rpm	294(400)/2700			
Non-load rotation speed(Max./Min)		rpm	2900±25/450 <sup>+50</sup> <sub>0</sub>			
Starting system			Electric starting, 24V-4kW			
Firing order			1-4-2-6-3-5-1			
Direction of rotation (viewed from stem )	Crankshaft		Counter-clockwise			
	Propeller shaft		Bi-rotation			
Lub. oil capacity	Max.	ℓ	33			
	Effect	ℓ	19			
Marine gear	Model		YX-71-1			
	Type		Hydraulic wet multi-disk type			
	Reduction ratio(forward)		2.07	2.58	2.91	
	Propeller shaft speed(at cont. rating)	rpm	1255	1006	894	
	Direction of rotation(propeller shaft)		Clockwise or counterclockwise viewed from stern			
	Dry weight	kg	210			
	Lubricating oil capacity	Max.	ℓ	6		
		Effective	ℓ	0.5		
Hydraulic oil pressure	kgf/cm <sup>2</sup>	22±5				
Fuel system	Fuel injection pump		In-line type			
	Injection timing		b.T.D.C 13°±1			
	Type of in jection nozzle degree		Hole type 6-φ0.28×155°			
	Injection pressure	MPa(kgf/cm <sup>2</sup> )	23.5±0.5(240±5)			
	Applicable fuel		Diesel oil or light oil(Cetane valve≥45)			
	Fuel filter		Paper element			
Engine lub. oil system	Lubrication		Forced lubrication by geared pump			
	Lub. oil discharge volume	ℓ /hr./rpm	≥6720/2600			
	Lub. oil pressure	kgf/cm <sup>2</sup>	5±0.5			
	Lub. oil		API Service grade CD			
	Lub. oil filter		(Suction side) Perforated steel plate	(Discharge side) Paper element		
Cooling water system	Sea water pump		Rubber impeller type, gear driving type			
	Freshwater pump		Center type, V-belt driving type			
	Cooling		Fresh water cooling			
	Pump discharge volume	ℓ /hr./rpm	Seawater: ≥9820/2600	Fresh water : ≥13000/2600		
	Fresh water capacity inside engine	ℓ	33			
	Fresh water capacity in sub-tank	ℓ	0.8			
Turbo charger	Type		HOLSET HX50			
	Cooling		Air cooling			
	Lubrication		Common with engine			
Air cooler	Type and capacity		Fin tube type 6.5m <sup>2</sup>			
	Cooling		Seawater cooling			
Engine dimension : Overall length×overall width×overall height		mm	1586×897×964			



## 2. Disassembly and Reassembly

### 2-1. Preparations before Disassembly and Reassembly

#### 2-1-1 Visual Mark List for Disassembly and Reassembly

Visual Mark		Visual Mark	
	See		※1 Apply liquid packing
	Caution		Safety
	Measure		Clean
	Oil supply		※2 Use torque wrench

※1 THREE BOND 3B-388-055

※2 The figure shows the widths across flat of the hexagonal part.

#### 2-1-2 Disassembly

- (1) Prepare the disassembly tools, measuring devices and record forms.
- (2) Prepare the cleaning machine and cleaning cans.
- (3) Prepare a place for putting parts and parts containers.
- (4) Extract cooling water and lube oil.
- (5) Put the disassembled parts in order.
- (6) Return bolts and nuts to their original positions temporarily to avoid confusion with different bolt and nut types.
- (7) Locate the cause of trouble accurately before disassembly, and do not remove or disassemble unnecessary parts.


#### 2-1-3 Reassembly

- (1) Clean and inspect the disassembled parts completely.
- (2) Apply clean engine oil to the sliding and rotational parts before installation.
- (3) Replace all gaskets and O-rings.
- (4) Apply liquid packing to the necessary parts to prevent water or oil leakage.
- (5) Check and ensure the correct oil and thrust clearance during reassembly.
- (6) Install the parts according to the alignment marks when they are provided. Take care of the combination of the parts with selective engagement.
- (7) Do not mix up bolts, nuts and washers. Tighten the major bolts and nuts to the specified tightening torque. Take special care when tightening aluminum alloy parts.
- (8) Apply engine oil to the threads and seat of the major bolts and tighten them to the specified tightening torque.






## 2-2. Disassembly and Reassembly Tools

### Standard tools

The following are the standard disassembly and reassembly tools:




Name of tool	Size	Shape
Double-head wrench	8 × 10, 12 × 14, 13 × 17 19 × 22, 24 × 27	(for removing fuel valve)
Wrench	7, 26	
Adjustable wrench	200	
Screw driver	⊕, ⊖ changeable	
Hexagon bar wrench	(for clutch emergency bolt)	
Double-head wrench	17 × 19	
Pliers		
Box wrench	19 × 12 (for cyl. head) 13 × 17 (for fuel oil pump)	
Extractor	(for fuel valve adiabatic packing) 127610-92910	
Extractor	(for removing fuel valve) 127616-92500	
Clearance gauge	(for adjusting intake/exhaust valve clearance)	
Hammer		
Filter wrench	(for removing filters) 127610-92750	
Oiler		
Turning handle		

### Tools (to be specially ordered)





Name of tool	Code No.	Shape
Socket (for rod bolt)	127610-92730	
Extractor for valve guide	127411-92160	
Extractor for fuel oil valve	127616-92500	
Piston insertion tool	122310-92140	
Piston rings fitting/removal tool	135410-92140	
Oil pan potitioning tool	1. Bolt (4pcs) 127610-92700 2. Spacers A 127610-92680 3. Spacers B 127610-92690	

Name of tool	Code No.	shape
Fresh water pump impeller (cam gear puller) (Press-fitting type)	1. Spacer 127610-92430 2. Bolt 124160-77511 3. Bolt (for impeller) × 2 26116-060302 4. Bolt (for cam gear) × 2 26116-080502	
Automatic timer tool (adiabatic material puller)	158591-54120 158591-54200	
Adiabatic material puller	127610-92910 (Standard)	
Protector puller	127695-92910	
Stem seal insertion tool		
Valve guide puller		



Name of tool	Code No.	shape
Exhaust manifold puller		
Fuel valve puller tool 127616-92500		

Special tools for clutch

No.	Name of tool	Note	shape
1	Emergency bolt span	For tightening the emergency bolt on clutch failure	
2	Gear puller		
3	Bearing separator	For removing bearing; used together with the gear puller	
4	Hydraulic fitting tool	For disassembly of output shaft joint Output shaft joint and large gear	












Name		for using		
Liquid packing (THREEBOND auxiliary packing):		<p>The silver grey semi-dry type viscoelastic liquid packing based on extreme heat-resisting synthetic rubber and synthetic resin. Apply the packing to the seal surface and join the part after several minutes when the packing has become semi-dry.</p> <p>The white liquid packing based on nylon resin. Brush the packing on the seal surface and join the part after several minutes when the packing has become semi-dry.</p> <p>Be sure to stir well before use.</p>		
White paint		Coat the paint on the contact area with the cylinder body before inserting the cylinder liner to prevent rust and water leakage. (Use the oil type make-up paint.)		
Name		quantity	Code No	Note
Scale removing agent	UNICON	1 case (4kg × 4)	974100-01460	<p>The strong scaling agent removes scale quickly (1-10 hrs.).</p> <p>Dissolve the agent in 10 parts of water or seawater (by weight ratio) and stir it well.</p> <p>Scale can be removed by just immersing the disassembled parts. To speed up the treatment, stir the solution. When the cleaning performance drops, neutralize the solution and throw it away.</p>
	Counteragent (caustic soda)	1 case (2kg × 4)	974100-0200	
	PH test paper	1 set	974100-04200	
Anti-rust agent		—	—	Mix the agent in ten parts of fresh water and stir the solution by operating the engine for about 5 minutes. The anti-rust performance lasts for about 6 months.
Coolant		—	—	Can be used both as anti-freeze in winter and coolant in summer. The performance lasts for 2 years.











Name	quantity	Code No	using
Metal Clean Y (cleaning agent)	1kg × 20	975600-02000	<p>Has strong performance to remove accumulated carbon.</p> <p>Can safely be heated to double the cleaning performance.</p> <p>Corrodes almost no metals, including iron. (Also has anti-rust effect.)</p> <p>To use, dissolve 1kg of the agent in 40 liters of water.</p> <p>When a cleaning machine is used, use 4-6% solution and heat in to 60-80°C.</p> <p>This will further raise the effect.</p>
Blower Clean (Special cleaning agent for turbocharger)	4 ℓ × 4	919200-10000	Special cleaning agent for turbocharger blower. Needs on water washing.
	18 ℓ × 1	919200-30000	
	1500cc × 6	919200-20000	


Measuring Device









Name	quantity	Code No	using
Cap tester	RCT-2A	955000-055000	For testing the radiator and the cap.








## 2-3. Reassembly Procedures

No.	Item	Procedure	Tool & Caution	Illustration				
1	Cylinder Block	<p>Clean the bearing holes completely. Reverse the cylinder block before reassembly.</p> <table border="1" data-bbox="392 405 732 506"> <tr> <td>T-plug 1/8 tightening torque</td> <td>0.5kgf · m</td> </tr> </table>	T-plug 1/8 tightening torque	0.5kgf · m		 <p>Cylinder Block</p>		
T-plug 1/8 tightening torque	0.5kgf · m							
2	Piston Cooling Nozzle	<p>Install the nozzle correctly according to the positioning pin. Take care not to over-tighten the nozzle.</p> <table border="1" data-bbox="392 786 732 846"> <tr> <td>Tightening torque</td> <td>2.0kgf·m</td> </tr> </table> <p>Check carefully that there are no chips or dust in the oil holes of the nozzle body, nozzle installation hole and check nozzle. Check that the nozzle body does not touch the cylinder block.</p>	Tightening torque	2.0kgf·m	 	 <p>Piston Cooling Nozzle</p>		
Tightening torque	2.0kgf·m							
3	Cam Shaft	<p>Apply lube oil to the cam shaft journal. Insert the cam shaft. Install the thrust plate.</p> <table border="1" data-bbox="392 1245 732 1305"> <tr> <td>Tightening torque</td> <td><math>2.6 \pm 0.2</math> kgf·m</td> </tr> </table> <p>Measure the side clearance.</p> <table border="1" data-bbox="392 1379 732 1480"> <tr> <td>Side clearance</td> <td>0.10–0.25mm</td> </tr> </table> <p>Installation of cam shaft metal. Replace the cam shaft metal as follows:</p> <ol style="list-style-type: none"> <li>Apply lube oil to the outside circumference of the cam shaft metal and the inside bore of the block.</li> <li>Align the oil hole so that the joint of the winding metal comes to the upper side.</li> <li>Overlapping of not less than 2mm will suffice for the alignment of the oil holes of the block and cam shaft metal. (Check the alignment after knocking in the cam shaft metal.)</li> </ol> <div data-bbox="400 1883 687 1989">  <p>Hole more than 2mm</p> </div>	Tightening torque	$2.6 \pm 0.2$ kgf·m	Side clearance	0.10–0.25mm	  	 <p>Cam Shaft</p>  <p>Installation of the thrust metal</p>
Tightening torque	$2.6 \pm 0.2$ kgf·m							
Side clearance	0.10–0.25mm							





No.	Item	Procedure	Tool & Caution	Illustration						
4	Cooling Water Passage Cover	Install the cooling water passage cover.	 12							
5	Crankshaft and Main Bearing	<p>The upper bearing (block side) has an oil groove; no oil groove in the lower bearing. The standard bearing is at the flywheel side (with flange).            Apply lube oil to the crank and assemble. Confirm the alignment number on the bearing cap and block. Assemble with the F-mark at the flywheel side.            Apply lube oil to the bolt threads and seat face and tighten the bolt to the specified tightening torque.            Turn manually to check that it turns lightly.            Measure the side clearance.</p> <table border="1" data-bbox="403 842 802 1068"> <tr> <td>Cap bolt tightening torque</td> <td><math>28 \pm 1.0</math> kgf-m</td> </tr> <tr> <td>Side clearance</td> <td>0.155-0.296mm</td> </tr> <tr> <td>Crankshaft bearing oil clearance</td> <td>0.04-0.108mm</td> </tr> </table>  <p>Fitting the cap bolt</p>  <p>Measure the side clearance</p>	Cap bolt tightening torque	$28 \pm 1.0$ kgf-m	Side clearance	0.155-0.296mm	Crankshaft bearing oil clearance	0.04-0.108mm	   24	 <p>Fitting the upper bearing</p>  <p>Fitting the crank shaft</p>  <p>Apply lube oil</p>  <p>Fitting the bearing cap</p>
Cap bolt tightening torque	$28 \pm 1.0$ kgf-m									
Side clearance	0.155-0.296mm									
Crankshaft bearing oil clearance	0.04-0.108mm									

No.	Item	Procedure	Tool & Caution	Illustration						
6	Idle Gear (Lube Oil Pump)	<p>Check the gear side clearance.</p> <table border="1" data-bbox="400 304 756 405"> <tr> <td data-bbox="400 304 555 405">Gear side clearance</td> <td data-bbox="555 304 756 405">0.066–0.114mm</td> </tr> </table> <p>Check the gear backlash.</p> <table border="1" data-bbox="400 461 756 562"> <tr> <td data-bbox="400 461 555 562">Gear backlash</td> <td data-bbox="555 461 756 562">0.08–0.16mm</td> </tr> </table> <p>Install the idle gear to the cap.</p> <table border="1" data-bbox="400 618 756 674"> <tr> <td data-bbox="400 618 555 674">Tightening torque</td> <td data-bbox="555 618 756 674">1.5–2.0kgf-m</td> </tr> </table>	Gear side clearance	0.066–0.114mm	Gear backlash	0.08–0.16mm	Tightening torque	1.5–2.0kgf-m		 <p data-bbox="1086 636 1305 667">Fitting the idle gear</p>
Gear side clearance	0.066–0.114mm									
Gear backlash	0.08–0.16mm									
Tightening torque	1.5–2.0kgf-m									







No.	Item	Procedure	Tool & Caution	Illustration				
7	Lube Oil Pump	<p>Install the lube oil assembly. Install the suction and discharge pipes.</p> <table border="1" data-bbox="384 327 799 427"> <tr> <td>(Bolt head width 12) Tightening torque</td> <td><math>2.5^{\pm 0.2}</math> kgf-m</td> </tr> </table> <p>Check the gear backlash (to the crankshaft).</p> <table border="1" data-bbox="384 483 799 584"> <tr> <td>Backlash for crank gear</td> <td>0.12–0.22mm</td> </tr> </table>  <p>Fitting to the suction pipe</p>	(Bolt head width 12) Tightening torque	$2.5^{\pm 0.2}$ kgf-m	Backlash for crank gear	0.12–0.22mm	<p>Wrench 12</p> <p>Wrench 14</p> 	 <p>Fitting to the lube oil pump</p>  <p>Fitting to the Safety valve and discharge pipe</p>
(Bolt head width 12) Tightening torque	$2.5^{\pm 0.2}$ kgf-m							
Backlash for crank gear	0.12–0.22mm							
8	Gear Case	<p>Install the bolt for fixing the fuel pump and the stud bolt for fixing the seawater pump to the gear case in advance. Match up the mounting surfaces of the oil pan. Align the positioning pin to the block and install the gear case.</p> <table border="1" data-bbox="384 1361 799 1462"> <tr> <td>(Bolt head width 12) Tightening torque</td> <td><math>2.6^{\pm 0.2}</math> kgf-m</td> </tr> </table> <p>Cut off the protruding packing.</p>	(Bolt head width 12) Tightening torque	$2.6^{\pm 0.2}$ kgf-m	<p>Wrench 12</p>	 <p>Fitting the gear case</p>		
(Bolt head width 12) Tightening torque	$2.6^{\pm 0.2}$ kgf-m							
9	Oil Pan	<p>Bring the gear case level so that the packing will not break. (Use the fitting tool.)</p> <table border="1" data-bbox="384 1615 799 1715"> <tr> <td>(Bolt head width 12) Tightening torque</td> <td><math>2.6^{\pm 0.2}</math> kgf-m</td> </tr> </table> <p>After tightening, cut off the packing protruding on the wheel housing side.</p> <p><i>Note :</i></p> <p><i>Apply the liquicl packing to both sides of the packing at the three-face joint of the gear case and flywheel side. Match up the installation faces of the wheel housing.</i></p> <table border="1" data-bbox="384 1973 799 2074"> <tr> <td>Step of the joint face at the flywheel housing side</td> <td>0.1mm</td> </tr> </table>	(Bolt head width 12) Tightening torque	$2.6^{\pm 0.2}$ kgf-m	Step of the joint face at the flywheel housing side	0.1mm	<p>Wrench 12</p>  	 <p>Fit the oil pan using the tool</p>
(Bolt head width 12) Tightening torque	$2.6^{\pm 0.2}$ kgf-m							
Step of the joint face at the flywheel housing side	0.1mm							





No.	Item	Procedure	Tool & Caution	Illustration						
10	Flywheel Housing	<p>Assemble the flywheel housing according to the positioning parallel pin.</p> <table border="1" data-bbox="370 322 810 403"> <tr> <td>Deviation at the oil seal insertion area</td> <td>less than 0.2mm</td> </tr> </table> <table border="1" data-bbox="370 430 810 510"> <tr> <td>Face deviation from the crankshaft center</td> <td>less than 0.3mm</td> </tr> </table> <table border="1" data-bbox="370 537 810 618"> <tr> <td>Flywheel housing tightening torque</td> <td><math>5 \pm 0.5</math> kgf-m</td> </tr> </table> <p>Install the lube oil piping (flywheel housing-oil filter).</p>	Deviation at the oil seal insertion area	less than 0.2mm	Face deviation from the crankshaft center	less than 0.3mm	Flywheel housing tightening torque	$5 \pm 0.5$ kgf-m		 <p>Assemble the Fly wheel housing</p>
Deviation at the oil seal insertion area	less than 0.2mm									
Face deviation from the crankshaft center	less than 0.3mm									
Flywheel housing tightening torque	$5 \pm 0.5$ kgf-m									
11	Oil Seal Case	<p>Press-fit the seal into the oil seal case (with the press-fitting tool ).</p> <p>Note :</p> <table border="1" data-bbox="370 833 810 913"> <tr> <td colspan="2"><i>(Apply lube oil to the outside lip of the oil seal before press-fitting.)</i></td> </tr> </table> <p>Install the oil seal case assembly to the flywheel side with its oil escape hole vertical.</p>	<i>(Apply lube oil to the outside lip of the oil seal before press-fitting.)</i>		 	 <p>Assemble the oil seal case</p>				
<i>(Apply lube oil to the outside lip of the oil seal before press-fitting.)</i>										
12	Engine Foot	<p>Install the engine foot.</p>		 <p>Install the engine foot</p>						
13	Tappets Tappet housing cover	<p>① Insert tappet into cylinder block bore. (Apply engine oil to tappet before inserting and check to see that it is not catching on anything when inserted.)</p> <table border="1" data-bbox="370 1639 810 1720"> <tr> <td>Tappet bore Oil clearance</td> <td>0.04~0.082mm</td> </tr> </table> <p>② Attach tappet housing cover after all tappets have been inserted.</p> <table border="1" data-bbox="370 1845 740 1926"> <tr> <td>(Dihedral width 12) Tightening torque</td> <td>1.2~1.7kg-m</td> </tr> </table>	Tappet bore Oil clearance	0.04~0.082mm	(Dihedral width 12) Tightening torque	1.2~1.7kg-m		 <p>(Insert tappet.)</p>  <p>(Attach tappet housing cover.)</p>		
Tappet bore Oil clearance	0.04~0.082mm									
(Dihedral width 12) Tightening torque	1.2~1.7kg-m									



No.	Item	Procedure	Tool & Caution	Illustration				
14	Tappets and Tappets Case cover	<p>Insert the tappets into the cylinder block hole. (Apply engine oil to the tappets. Move the tappets manually to check that they are inserted smoothly.)</p> <table border="1" data-bbox="384 427 812 528"> <tr> <td>Tappet hole oil clearance</td> <td>0.04 – 0.082mm</td> </tr> </table> <p>Install the tappet case cover after inserting all tappets.</p> <table border="1" data-bbox="384 622 812 723"> <tr> <td>(Bolt head width 12) Tightening Torque</td> <td>1.2 – 1.7kgf-m</td> </tr> </table>	Tappet hole oil clearance	0.04 – 0.082mm	(Bolt head width 12) Tightening Torque	1.2 – 1.7kgf-m	  	  <p>Tappet</p>
Tappet hole oil clearance	0.04 – 0.082mm							
(Bolt head width 12) Tightening Torque	1.2 – 1.7kgf-m							
15	Cylinder Sleeve	<p>Clean the sleeve fitting area of the cylinder block completely. Clean the outside circumference of the cylinder sleeve completely and insert it manually into the cylinder block.</p> <p><i>Note :</i></p> <div data-bbox="384 1039 812 1518" style="border: 1px solid black; padding: 5px;"> <p><i>Before inserting the cylinder sleeve, check the cylinder number and the insertion direction. (Size code is for the cylinder sleeve) (Identical code for the cylinder block and sleeve) (Make a combination of A, B, C and D.) (Direct the code side to the anti-operation side.) (Marked in black paint at the anti-operation side.) Do not place on the cylinder head face after inserting the cylinder sleeve. Be sure to assemble the cylinder sleeve manually. (Do not use a hammer.)</i></p> </div> <p>Measure the protrusion of the cylinder liner.</p> <table border="1" data-bbox="421 1597 775 1659"> <tr> <td>Liner protrusion</td> <td>0.03 – 0.09mm</td> </tr> </table> <p>Measure the distortion of the cylinder liner.</p> <table border="1" data-bbox="421 1767 775 1830"> <tr> <td>Cylindricity</td> <td>less than <math>\leq 0.015\text{mm}</math></td> </tr> </table> <p>(The mark at the cylinder block side is punched on the head joint face of the operation side.)</p>	Liner protrusion	0.03 – 0.09mm	Cylindricity	less than $\leq 0.015\text{mm}$		 <p>Cylinder sleeve</p> <p>Size code is for the cylinder sleeve. Marked in black paint at the anti-operation side.</p> <div data-bbox="1043 1570 1362 1877" style="text-align: center;"> <p>「BM」</p> <p>↑ ↑</p> <p>Piston fitting code</p> <p>↑</p> <p>Cylinder block fitting code</p> </div>
Liner protrusion	0.03 – 0.09mm							
Cylindricity	less than $\leq 0.015\text{mm}$							



No.	Item	Procedure	Tool & Caution	Illustration				
18	Piston and Connecting Rod	<p>Assemble the connecting rod to the piston. The size code, ML or MS, is provided on the piston head. Match up the code with the correctly code of the cylinder sleeve. Distribute the end gaps of the piston rings evenly on the piston. Insert the piston into the cylinder liner, placing the con. rod alignment mark on the operation side. Apply lube oil. Confirm the alignment marks on the connecting rod and cap, and install the cap. Apply lube oil to the thread seat face and tighten the rod bolt to the specified tightening torque. Tighten the bolts by turns evenly 3 times to avoid uneven tightening.</p> <table border="1" data-bbox="408 719 756 815"> <tr> <td>Tightening torque</td> <td><math>23 \pm 0.5</math> kgf-m</td> </tr> </table> <p>Measure the side clearance after tightening the bolts.</p> <table border="1" data-bbox="408 898 801 994"> <tr> <td>Rod large end side clearance</td> <td>0.15-0.35mm</td> </tr> </table> <p>Install the cylinder block side cover. (An alignment mark is provided on the rod bolt. This is because a torque wrench cannot be used in restricted engine room spaces.)</p> 	Tightening torque	$23 \pm 0.5$ kgf-m	Rod large end side clearance	0.15-0.35mm		 <p>Assemble the piston and con.rod.</p>  <p>alignment mark</p>  <p>Fitting the side cover</p>  <p>Fitting the gear case cover</p>
Tightening torque	$23 \pm 0.5$ kgf-m							
Rod large end side clearance	0.15-0.35mm							
19	Gear Case Cover	<p>Install the oil seal to the gear case.</p> <p><i>Note :</i> Apply lube oil to the exterior and lip of the oil seal before press-fitting it.</p> <p>Install the gear case cover.</p> <p><i>Note :</i> The positioning pin (spring pin) is provided at the joint face of the gear case and cylinder block.</p> <p>Measure the face deviation of the front drive installation.</p> <table border="1" data-bbox="384 1872 793 1968"> <tr> <td>Face deviation</td> <td>Less than 0.05mm for crank center</td> </tr> </table>	Face deviation	Less than 0.05mm for crank center				
Face deviation	Less than 0.05mm for crank center							

No.	Item	Procedure	Tool & Caution	Illustration			
20	Bearing Case	Install the sea water pump drive bearing case. Install the V-pulley. Bend the washer after tightening the nut. Install the breather.		 <p data-bbox="1038 629 1321 651">Assemble the bearing case</p>  <p data-bbox="1075 1032 1283 1055">Install the V-pulley</p>			
21	Flywheel	Install the flywheel. (Align the positioning parallel pin holes.) Tighten the bolts to the specified tightening torque. <table border="1" data-bbox="384 1211 730 1312"> <tr> <td>Tightening torque</td> <td><math>29 \pm 1</math> kgf-m</td> </tr> </table> Measure and check the flywheel face deviation and centering location deviation. <table border="1" data-bbox="384 1424 762 1480"> <tr> <td>Face deviation</td> <td>less than 0.13mm</td> </tr> </table> Follow the instructions below when replacing the top indication plate: 1) Bring the No.1 piston at the flywheel side to the top position. (Check using the dial gauge.) 2) Install aligning the top punched line of the flywheel to the piston top position. 3) The alignment error between the top mark of the indication plate and the top punched line of the flywheel should be within +30 min.	Tightening torque	$29 \pm 1$ kgf-m	Face deviation	less than 0.13mm	 <p data-bbox="1062 1541 1299 1563">Assemble the flywheel</p>  <p data-bbox="1062 2011 1299 2033">Check the No1 cyl.top.</p>
Tightening torque	$29 \pm 1$ kgf-m						
Face deviation	less than 0.13mm						