
Service Manual Outline

Section 1 - Important Information

- A - General Information
- B - Maintenance
- C - Troubleshooting

Section 2 - Removal and Installation

- A - MCM Models

Section 3 - Engine

- A - 262 CID / 4.3L Engines

Section 4 - Electrical Systems

- A - Starting System
- B - Ignition System
- C - Charging System
- D - Instrumentation
- E - Wiring Diagrams

Section 5 - Fuel Systems

- A - Fuel Delivery System For Carbureted Engines
- B - Mercarb® 2 Barrel Carburetor
- C - Weber 4 Barrel Carburetor
- D - SAV1 Emission Fuel System With Weber Carburetor
- E - Fuel Delivery System For Electronic Fuel Injection
- F - Fuel Injection Descriptions And System Operation
- G - Fuel Injection Disassembly And Reassembly
- H - Fuel Injection System Troubleshooting
- I - Diagnostics

Section 6 - Cooling System

- A - Seawater Cooled Models
- B - Closed Cooled Models

Section 7 - Exhaust System

- A - General
- B - Manifolds, Elbows and Risers
- C - Collectors

Section 8 - Drives

- A - Drive Shaft Models

Section 9 - Power Steering System

- A - Pump and Related Components

Important Information

1

Removal and Installation

2

Engine

3

Electrical Systems

4

Fuel Systems

5

Cooling System

6

Exhaust System

7


Drives

8

Power Steering System

9

Notice

Throughout this publication, “Dangers,” “Warnings” and “Cautions” (accompanied by the International HAZARD Symbol ) are used to alert the mechanic to special instructions concerning a particular service or operation that may be hazardous if performed incorrectly or carelessly. **OBSERVE THEM CAREFULLY!**

These “Safety Alerts” alone cannot eliminate the hazards that they signal. Strict compliance to these special instructions when performing the service, plus “Common Sense” operation, are major accident prevention measures.

DANGER

DANGER - Immediate hazards which WILL result in severe personal injury or death.

WARNING

WARNING - Hazards or unsafe practices which COULD result in severe personal injury or death.

CAUTION

Hazards or unsafe practices which could result in minor personal injury or product or property damage.

Notice to Users of This Manual

This service manual has been written and published by the Service Department of Mercury Marine to aid our dealers’ mechanics and company service personnel when servicing the products described herein.

It is assumed that these personnel are familiar with the servicing procedures of these products, or like or similar products manufactured and marketed by Mercury Marine, that they have been trained in the recommended servicing procedures of these products which includes the use of mechanics’ common hand tools and the special Mercury Marine or recommended tools from other suppliers.

We could not possibly know of and advise the service trade of all conceivable procedures by which a service might be performed and of the possible hazards and/or results of each method. We have not undertaken any such wide evaluation. Therefore, anyone who uses a service procedure and/or tool, which is not recommended by the manufacturer, first must completely satisfy himself that neither his nor the products safety will be endangered by the service procedure selected.

All information, illustrations and specifications contained in this manual are based on the latest product information available at the time of publication. As required, revisions to this manual will be sent to all dealers contracted by us to sell and/or service these products.

It should be kept in mind, while working on the product, that the electrical system and ignition system are capable of violent and damaging short circuits or severe electrical shocks. When performing any work where electrical terminals could possibly be grounded or touched by the mechanic, the battery cables should be disconnected at the battery.

Any time the intake or exhaust openings are exposed during service they should be covered to protect against accidental entrance of foreign material which could enter the cylinders and cause extensive internal damage when the engine is started.

It is important to note, during any maintenance procedure replacement fasteners must have the same measurements and strength as those removed. Numbers on the heads of the metric bolts and on the surfaces of metric nuts indicate their strength. American bolts use radial lines for this purpose, while most American nuts do not have strength markings. Mismatched or incorrect fasteners can result in damage or malfunction, or possibly personal injury. Therefore, fasteners removed should be saved for reuse in the same locations whenever possible. Where the fasteners are not satisfactory for re-use, care should be taken to select a replacement that matches the original.

We reserve the right to make changes to this manual without prior notification.

Refer to dealer service bulletins for other pertinent information concerning the products described in this manual.

Engine Mechanical Components

Many of the engine mechanical components are designed for marine applications. Unlike automotive engines, marine engines are subjected to extended periods of heavy load and wide-open-throttle operation and, therefore, require heavy-duty components. Special marine engine parts have design and manufacturing specifications which are required to provide long life and dependable performance. Marine engine parts also must be able to resist the corrosive action of salt or brackish water that will rust or corrode standard automotive parts within a short period of time.

Failure to use recommended Quicksilver service replacement parts can result in poor engine performance and/or durability, rapid corrosion of parts subjected to salt water and possibly complete failure of the engine.

Use of parts other than recommended service replacement parts, will void the warranty on those parts which are damaged as a result of the use of other than recommended replacement parts.

Replacement Parts

WARNING

Electrical, ignition and fuel system components on MerCruiser Engines and Stern-drives are designed and manufactured to comply with U.S. Coast Guard Rules and Regulations to minimize risks of fire or explosion.

Use of replacement electrical, ignition or fuel system components, which do not comply to these rules and regulations, could result in a fire or explosion hazard and should be avoided.

When servicing the electrical, ignition and fuel systems, it is extremely important that all components are properly installed and tightened. If not, any electrical or ignition component opening would permit sparks to ignite fuel vapors from fuel system leaks, if they existed.

Table of Contents

IMPORTANT INFORMATION

Section 1A - General Information

Introduction	1A-2	Propeller Information	1A-5
How to Use This Manual	1A-2	Water Testing New Engines	1A-6
Page Numbering	1A-2	Boat and Engine Performance	1A-6
How to Read a Parts Manual	1A-3	Boat Bottom	1A-6
Directional References	1A-4	Marine Fouling	1A-7
Engine Rotation	1A-4	Weight Distribution	1A-8
Engine Serial Number Location	1A-5	Water in Boat	1A-9
		Elevation and Climate	1A-9

Section 1B - Maintenance

Tools	1B-2	Closed Cooling System	1B-17
Lubricants / Sealants / Adhesives	1B-2	Checking Coolant Level	1B-17
Maintenance Schedules	1B-3	Flushing System	1B-18
Maintenance Intervals	1B-3	Lubrication	1B-20
Gas Sterndrive	1B-3	Throttle Cable	1B-20
Routine Maintenance *	1B-3	Shift Cable	1B-20
Scheduled Maintenance *	1B-4	Engine Coupler /	
Engine and Tune-Up Specifications	1B-5	U-Joint Shaft Splines	1B-21
MCM (Sterndrive)	1B-5	Sterndrive Drive	
Fluid Capacities	1B-6	Shaft Extension Models	1B-22
Sterndrive Engines	1B-6	Cleaning Flame Arrestor	1B-22
Sterndrives	1B-6	Top Mounted Flame Arrestor	1B-23
20-Hour Break-In Period	1B-7	Serpentine Drive Belt	1B-23
After Break-in Period	1B-7	Component Location	1B-23
End of First Season Checkup	1B-7	Serpentine Belt Routing	1B-24
Specifications	1B-8	S/N 0L619083 and Below	1B-24
Fuel Recommendations	1B-8	S/N 0L619084 and Above	1B-25
Test For Alcohol Content In Gasoline	1B-10	Inspection	1B-26
Power Steering Fluid	1B-10	Replacing and/or Adjusting Tension	1B-26
Coolant for Closed Cooling System	1B-10	Ignition Timing	1B-27
Crankcase Oil	1B-11	Thunderbolt V Models	1B-27
Overfilled Crankcase Oil	1B-11	EFI	1B-28
Checking Engine Oil Level / Filling	1B-12	Cold Weather or Extended Storage	1B-29
Changing Oil and Filter	1B-12	Precautions	1B-29
Changing Water Separating Fuel Filter	1B-13	Power Package Layup	1B-31
Power Steering System	1B-15	Draining Instructions	1B-33
Checking Fluid Level	1B-15	Draining Sterndrive	1B-38
Engine Cold	1B-15	Recommissioning	1B-39
Filling and Bleeding	1B-16		

Section 1C - Troubleshooting

Precautions	1C-2	Poor Fuel Economy	1C-14
Used Spark Plug Analysis	1C-3	Engine Runs Poorly at Idle	1C-14
Normal Condition	1C-3	Engine Runs Poorly At High RPM	1C-15
Chipped Insulator	1C-3	Engine Acceleration Is Poor	1C-16
Wet Fouling (Oil Deposits)	1C-4	Troubleshooting with Vacuum Gauge	1C-16
Cold Fouling	1C-4	Engine Noise	1C-17
Overheating	1C-4	Important Information	1C-17
High Speed Glazing	1C-5	Valve Cover Area	1C-17
Scavenger Deposits	1C-5	Cylinder Area	1C-18
Pre-Ignition Damage	1C-5	Camshaft Area	1C-18
Reversed Coil Polarity	1C-6	Crankshaft Area	1C-19
Splashed Deposits	1C-6	Miscellaneous	1C-20
Mechanical Damage	1C-6	Oil Pressure	1C-21
Poor Boat Performance and/or		Miscellaneous	1C-21
Poor Maneuverability	1C-7	Low Oil Pressure	1C-22
Improper Full Throttle Engine RPM	1C-8	High Oil Pressure	1C-22
RPM Too High	1C-8	Excessive Oil Consumption	1C-23
RPM Too Low	1C-8	Water In Engine	1C-24
Engine Cranks Over But Will Not Start		Important Information	1C-24
Or Starts Hard	1C-9	Water on Top of Pistons	1C-25
Important Information	1C-9	Water in Crankcase Oil	1C-25
Thunderbolt V Ignition (No Spark)	1C-10	Engine Overheats	1C-26
Testing Thunderbolt V Ignition System	1C-10	Mechanical	1C-26
Fuel System Rich	1C-11	Engine Overheats	1C-27
Fuel System Lean	1C-11	Cooling System	1C-27
Miscellaneous	1C-11	Insufficient Water Flow from	
Engine Will Not Crank Over	1C-12	Belt Driven Seawater Pickup Pump	1C-28
Charging System Inoperative	1C-12	Power Steering	1C-29
Noisy Alternator	1C-13	Poor, Erratic or No Assist	1C-29
Instrumentation Malfunction	1C-13	Noisy Pump	1C-30
Radio Noise	1C-13	Fluid Leaks	1C-30

REMOVAL AND INSTALLATION

Section 2A - MCM Models

Torque Specifications	2A-2
Tools	2A-2
Lubricants / Sealants / Adhesives	2A-2
Removal	2A-3
Installation and Alignment	2A-5
Engine Connections	2A-10
Electrical Connections	2A-11
Mercathode Connections	2A-12
Shift Cable Installation	2A-12
Power Steering Connections	2A-12
Fuel Supply Connections	2A-13
Throttle Cable Installation and	
Adjustment	2A-14

ENGINE

Section 3A - 262 cid (4.3L) Engines

Torque Specifications	3A-2	Removal	3A-62
Lubricants / Sealants / Adhesives	3A-4	Cleaning and Inspection	3A-63
Tools	3A-4	Installation	3A-63
Specifications	3A-6	Flywheel	3A-64
General	3A-11	Removal	3A-64
Bearing Failures	3A-14	Inspection	3A-64
Piston Failures	3A-16	Installation	3A-65
Pre-Ignition	3A-16	Rear Main Oil Seal	3A-66
Detonation	3A-17	Removal	3A-66
Engine Mounts	3A-19	Cleaning and Inspection	3A-67
Rocker Arm Cover	3A-20	Installation	3A-67
Removal	3A-20	Rear Main Oil Seal Retainer	3A-68
Installation	3A-20	Removal	3A-68
Intake Manifold	3A-21	Cleaning and Inspection	3A-68
Removal	3A-21	Installation	3A-68
Cleaning and Inspection	3A-23	Main Bearings	3A-69
Installation	3A-23	Inspection	3A-69
Rocker Arm / Push Rod	3A-27	Replacement	3A-71
Removal	3A-27	Connecting Rod Bearings	3A-74
Cleaning and Inspection	3A-28	Inspection and Replacement	3A-74
Installation	3A-28	Connecting Rod / Piston Assembly	3A-76
Hydraulic Roller Valve Lifters	3A-29	Removal	3A-76
Locating Noisy Lifters	3A-30	Disassembly	3A-77
Removal	3A-31	Cleaning and Inspection	3A-78
Cleaning and Inspection	3A-34	Reassembly	3A-80
Installation	3A-34	Installation	3A-82
Valve Stem Oil Seal / Valve Spring	3A-36	Crankshaft	3A-84
Removal - Head Installed	3A-36	Removal	3A-84
Valve Assembly (Exploded View)	3A-38	Cleaning and Inspection	3A-86
Installation - Head Installed	3A-39	Installation	3A-87
Cylinder Head	3A-40	Timing Chain and Sprocket	3A-88
Removal	3A-40	Exploded View	3A-88
Cleaning and Inspection	3A-42	Removal	3A-88
Installation	3A-43	Cleaning and Inspection	3A-89
Cylinder Head and Valve Conditioning	3A-47	Installation - Timing Chain	3A-89
Disassembly	3A-47	Crankshaft Sprocket	3A-89
Cleaning	3A-47	Removal	3A-89
Inspection	3A-48	Installation	3A-89
Valve Guide Bore Repair	3A-49	Checking Timing Chain Deflection ..	3A-90
Valve Springs - Checking Tension	3A-50	Balance Shaft / Gears	3A-91
Valve Seat Repair	3A-50	Removal	3A-91
Valve Grinding	3A-51	Cleaning and Inspection	3A-94
Reassembly	3A-52	Installation	3A-94
Dipstick Specifications	3A-55	Camshaft	3A-96
Oil Pan	3A-56	Measuring Lobe Lift	3A-96
Removal	3A-56	Removal	3A-97
Installation	3A-56	Inspection	3A-98
Oil Pump	3A-57	Installation	3A-98
Removal	3A-57	Camshaft Bearings	3A-99
Disassembly	3A-58	Removal	3A-99
Cleaning and Inspection	3A-58	Inspection	3A-100
Reassembly	3A-58	Installation	3A-100
Installation	3A-59	Cylinder Block	3A-101
Torsional Damper	3A-59	Cleaning and Inspection	3A-101
Removal	3A-59	Oil Filter By-Pass Valve	3A-105
Installation	3A-60	Inspection and/or Replacement	3A-105
Crankcase Front Cover Oil Seal	3A-61	Remote Oil Filter	3A-106
Crankcase Front Cover	3A-62	Inspection and/or Replacement	3A-106

Section 4A - Starting Systems

Identification	4A-2	Periodic Inspection	4A-13
Replacement Parts Warning	4A-2	Motor	4A-13
General Precautions	4A-2	Removal	4A-13
Starting System Components	4A-3	Disassembly	4A-13
Positive Current Flow	4A-4	Cleaning and Inspection	4A-16
Battery	4A-4	Reassembly	4A-17
Battery Cable Recommendations	4A-4	Checking Pinion Clearance	4A-21
Maintenance	4A-6	Installation	4A-22
Testing	4A-7	Delco PG260 Starter	4A-23
Storage	4A-7	PG260 Specifications	4A-23
Charging Guide	4A-8	Torque Specification	4A-23
How Temperature Affects		Lubricants / Sealants	4A-23
Battery Power	4A-8	Description	4A-23
Standard Starter Slave Solenoid	4A-9	PG260 Exploded View	4A-24
Identification	4A-9	Solenoid Switch	4A-25
Standard Type Slave Solenoid	4A-9	Periodic Inspection	4A-25
Testing / Replacement	4A-9	Motor	4A-26
Installation	4A-10	Removal	4A-26
Permanent Magnet - Gear Reduction		Disassembly	4A-26
(PG260F1) Starter Motor	4A-10	Cleaning and Inspection	4A-30
Starter Specifications	4A-10	Armature Tests	4A-31
Torque Specifications	4A-10	Armature Bearing (Commutator End)	4A-32
Lubricants / Sealants	4A-10	Gear Bearing	4A-32
Description	4A-11	Shaft Assembly Bearing	4A-33
PG260F1 Exploded View	4A-12	Drive End Housing Bearing	4A-33
Solenoid Switch	4A-13	Brushes and Brush Holder	4A-34

Section 4B - Thunderbolt V Ignition System

Replacement Parts Warning	4B-2	Circuit Description	4B-10
General Precautions	4B-2	Ignition Control Module	4B-10
EFI System Maintenance Precautions	4B-3	Knock Control Module	4B-10
Thunderbolt V Ignition System	4B-4	Ignition Control System Timing Lead	4B-10
Identification	4B-4	Thunderbolt V Spark Control Graph	4B-11
Timing and Idle Adjustment Procedures	4B-5	Distributor Advance Curves	4B-12
Setting Base Ignition Timing	4B-5	Distributor	4B-12
Adjusting Idle Mixture	4B-5	Removal	4B-12
Spark Plugs	4B-6	Disassembly	4B-13
Specifications	4B-6	Reassembly	4B-13
Removal	4B-6	Installation - Engine Not Disturbed	4B-14
Inspection	4B-6	Installation - Engine Disturbed	4B-14
Replacing	4B-7	Distributor Cap	4B-15
Description	4B-7	Removal	4B-15
Idle Speed Spark Control	4B-7	Inspection	4B-15
Acceleration Spark Advance	4B-8	Rotor/Sensor Wheel	4B-16
Mean-Best-Timing (MBT)		Removal	4B-16
Spark Advance	4B-8	Inspection	4B-16
Over-Speed Control	4B-8	Installation	4B-17
Knock Retard Spark Control	4B-8	Sensor	4B-17
Spark Plug Wires	4B-9	Removal	4B-17
Adjusting Engine Idle Speed	4B-9	Inspection	4B-18
		Installation	4B-18

Section 4C - Charging System

General Precautions	4C-2	Testing	4C-7
EFI Electrical System Precautions	4C-2	Charging System	4C-7
Replacement Parts Warning	4C-2	Charging System Resistance	4C-8
Multiple EFI Engine Battery Precautions	4C-3	Circuitry	4C-10
Situation	4C-3	Component	4C-11
Recommendations	4C-3	Exploded View	4C-16
Identification	4C-4	Alternator Repair	4C-17
Specifications	4C-4	Removal	4C-17
Mando	4C-4	Disassembly	4C-17
DelcoRemy	4C-5	Cleaning and Inspection	4C-22
Tools	4C-5	Reassembly	4C-22
Lubricants / Sealants / Adhesives	4C-5	Installation	4C-26
Torque Specifications	4C-5	Pulley Removal	4C-27
Description	4C-6	Battery Isolator Diagram	4C-28

Section 4D - Instrumentation

Tools	4D-2	Senders	4D-9
Lubricants / Sealants / Adhesives	4D-2	Oil Pressure	4D-9
Identification	4D-2	Water Temperature	4D-10
Special Information	4D-3	Fuel Tank Sender	4D-13
Lighting Options	4D-3	Switches	4D-16
Gauges	4D-5	Ignition Key Switch	4D-16
Oil, Fuel and Temperature	4D-5	Lanyard Stop Switches	4D-17
Battery Gauge	4D-6	Testing	4D-17
Cruiselog Meter	4D-7	Start/Stop Switch	4D-19
Vacuum Gauge	4D-7	Audio Warning System	4D-20
Speedometer	4D-7	Buzzer	4D-20
Tachometer	4D-8	Oil Pressure Switch	4D-21
Gauge Replacement	4D-8	Water Temperature Switch	4D-21

Section 4E - Wiring Diagrams

Wiring Colors for Mercury MerCruiser ..	4E-2
MCM Gasoline Engine Wiring Diagrams	4E-4
Starting and Charging Harness	4E-4
Fuel and Ignition System Harnesses	4E-16
Quicksilver Instrumentation	4E-22
Dual Station Wiring	4E-24

FUEL SYSTEM

Section 5A - Fuel Delivery System For Carbureted Engines

Identification	5A-2	Fuel Delivery System	5A-4
Replacement Parts Warning	5A-2	Recommendations	5A-4
Specifications	5A-2	Fuel System Components	5A-6
Torque Specifications	5A-2	Water Separating Fuel Filter	5A-7
Tools	5A-3	Replacement	5A-8
Lubricants / Sealants / Adhesives	5A-3	Vent Hose Routing	5A-8
Precautions	5A-3	Carbureted Models	5A-8
Fuel Supply Connections	5A-3		

Section 5B - Mercarb® 2 Barrel Carburetor

Identification	5B-2	Maintenance	5B-11
Replacement Parts Warning	5B-3	Flame Arrestor	5B-11
Precautions	5B-3	Fuel Inlet Filter	5B-13
Torque Specifications	5B-3	Choke Inspection	5B-14
Specifications	5B-4	Adjustments	5B-14
Tools	5B-4	Accelerator Rod	5B-14
Exploded View	5B-6	Choke Setting	5B-16
Important Service Information	5B-8	Choke Unloader	5B-17
High Altitude Re-Jetting	5B-8	Initial Idle Speed and Mixture	5B-17
8 Point Carburetor Check List	5B-9	Final Idle Speed and Mixture	5B-18
Flooding At Idle RPM	5B-9	Replacing Carburetor	5B-18
Needle / Seat Change	5B-9	Repair	5B-19
Adjustable Accelerator Pump Lever	5B-10	Removal	5B-19
Description	5B-10	Disassembly	5B-20
		Cleaning and Inspection	5B-28
		Reassembly	5B-30
		Installation	5B-40

Section 5C - Weber 4 Barrel Carburetor

Identification	5C-2	Maintenance	5C-12
Carburetor Metering Rod And Jet Identification	5C-2	Flame Arrestor	5C-12
Torque Specifications	5C-4	Fuel Inlet Filter	5C-13
Specifications	5C-4	Adjustments	5C-14
Tools	5C-5	Accelerator Pump	5C-14
Replacement Parts Warning	5C-5	Float Drop	5C-16
Precautions	5C-6	Float Level	5C-17
Fuel Delivery System	5C-6	Electric Choke	5C-18
Fuel Supply Connections	5C-6	Idle Speed and Mixture	5C-18
8 Point Carburetor Check List	5C-7	Replacing Carburetor	5C-19
Exploded View	5C-8	Repair	5C-19
Description	5C-10	Removal	5C-19
Important Service Information	5C-11	Disassembly	5C-21
Adjustable Accelerator Pump Lever	5C-11	Cleaning and Inspection	5C-32
Hard Starting	5C-11	Reassembly	5C-33
		Installation	5C-44

Section 5D - Sav1 Emission Fuel System With Weber 4 Barrel Carburetor

Identification	5D-2	Troubleshooting	5D-8
Replacement Parts Warning	5D-2	Checking Ported Vacuum Switch and Carburetor Vacuum Circuit for Correct Operation	5D-9
Torque Specifications	5D-2	Service Procedures	5D-11
Special Tools	5D-2	Checking Positive Crankcase Ventilation (PCV) Valve	5D-11
Engine Specifications	5D-3	Removing Seals From Idle Mixture Screws	5D-11
Carburetor Specifications	5D-3	Installing New Seals	5D-12
Carburetor Adjustment Specifications	5D-4	Carburetor Installation	5D-12
Description	5D-4	Ported Vacuum Switch Installation	5D-13
Special Notes	5D-5	Emissions System Connections	5D-13
Carburetor Top Cover	5D-5	Propane Assisted Idle Set Procedure	5D-15
Sealed Idle Mixture Screws	5D-5	Test Equipment	5D-18
Piston Bore of Emissions Model	5D-6	Emissions Testing	5D-19
Precautions	5D-6		
Maintenance	5D-7		
Flame Arrestor	5D-7		
Fuel Filter	5D-7		
Positive Crankcase Ventilation (PCV)	5D-8		

Section 5E - Fuel Delivery System For Electronic Fuel Injection

Specifications	5E-2	Water Separating Fuel Filter	5E-7
Torque Specifications	5E-2	Water Separating Fuel Filter Replacement	5E-8
Tools	5E-2	Cool Fuel System Repair	5E-8
Lubricants / Sealants / Adhesives	5E-2	Removal	5E-8
Replacement Parts Warning	5E-2	Disassembly	5E-10
Precautions	5E-3	Reassembly	5E-11
Fuel Supply Connections	5E-3	Installation	5E-13
Fuel Delivery System	5E-4	Vacuum and Vent Hose Routing	5E-15
Recommendations	5E-4	Throttle Body EFI	5E-15
Cool Fuel System Exploded View	5E-5		
Fuel System Flow Diagrams	5E-6		
Throttle Body Injection	5E-6		

Section 5F - Fuel Injection Descriptions And System Operation

Special Tools	5F-2	Electronic Control Module (ECM) and Sensors	5F-13
Service Precautions	5F-3	General Description	5F-13
General Information	5F-5	Computers and Voltage Signals	5F-13
Introduction	5F-5	Analog Signals	5F-13
Visual/Physical Inspection	5F-5	Digital Signals	5F-14
Basic Knowledge and Tools Required	5F-5	Engine Control Module (ECM)	5F-15
Electrostatic Discharge Damage	5F-5	Speed Density System	5F-16
Diagnostic Information	5F-5	ECM Input and Sensor Descriptions	5F-17
Wiring Harness Service	5F-6	Spark Management	5F-22
Wiring Connector Service	5F-7	High Energy Ignition with Ignition Control (IC)	5F-22
Abbreviations	5F-8	Modes Of Operation	5F-23
ECM Self-Diagnostics	5F-9	Base Ignition Timing	5F-24
Diagnostic Code Tool With Malfunction Indicator Lamp	5F-9	Results of Incorrect Operation	5F-25
Intermittent Malfunction Indicator Lamp	5F-9	Fuel Metering System	5F-26
Reading Codes	5F-10	General Description	5F-26
Scan Tools	5F-11	Cool Fuel Systems	5F-26
EFI Diagnostic Circuit Check	5F-11	Modes of Operation	5F-26
Scan Tool Use With Intermittents	5F-11	Throttle Body Injection Components	5F-28
Non-Scan Diagnosis of Driveability Concerns (With No Codes Set)	5F-12		

Section 5G - Fuel Injection Disassembly And Reassembly

Precautions	5G-2	Throttle Body Adapter Plate	5G-17
Torque Specifications	5G-3	Engine Control Module (ECM)	5G-18
Flame Arrestor And Throttle Body	5G-4	Knock Sensor (KS) Module (MEFI 1 Only)	5G-19
Exploded Views - Throttle Body EFI	5G-7	Engine Coolant Temperature (ECT) Sensor	5G-20
Throttle Body Body And Adapter	5G-7	Manifold Absolute Pressure (MAP) Sensor	5G-21
Throttle Body Assembly	5G-8	Throttle Position (TP) Sensor	5G-22
Fuel Pressure Relief Procedure	5G-9	Idle Air Control (IAC) Valve	5G-23
Throttle Body EFI Components	5G-9	Knock Sensor	5G-25
Fuel Meter Cover Assembly	5G-9		
Fuel Injectors	5G-11		
Throttle Body	5G-13		

Section 5H - Fuel Injection System Troubleshooting

Scan Tool Normal Specifications	5H-2	Detonation / Spark Knock Symptom ...	5H-11
Important Preliminary Checks	5H-3	Hesitation, Sag, Stumble Symptom	5H-13
Before Starting	5H-3	Cuts Out, Misses Symptom	5H-15
Visual / Physical Check	5H-3	Rough, Unstable or Incorrect Idle, Stalling Symptom	5H-17
Intermittents	5H-4	Poor Fuel Economy Symptom	5H-20
Hard Start Symptom	5H-5	Dieseling, Run-On Symptom	5H-22
Surges and/or Chuggles Symptom	5H-7	Backfire Symptom	5H-23
Lack of Power, Sluggish or Spongy Symptom	5H-9		

Section 5I - Diagnostics

Special Tools	5I-2	Clearing Trouble Codes	5I-48
Diagnostic Circuit Check	5I-4	Clearing Codes Using CodeMate Tester	5I-48
Scan Tool Normal Specifications	5I-4	Clearing Codes Using Scan Tool	5I-48
Diagnostic Trouble Codes	5I-5	Diagnostic Testing	5I-49
ECM Connector and EFI Symptoms Chart	5I-6	Code 14 Engine Coolant Temperature (ECT) Sensor Circuit	5I-49
J-1 Circuits with MEFI 1	5I-6	Code 15 Engine Coolant Temperature (ECT) Sensor Circuit	5I-52
J-2 Circuits with MEFI 1	5I-8	Code 21 Throttle Position (TP) Sensor Circuit	5I-54
J-1 Circuits with MEFI 3	5I-10	Code 22 Throttle Position (TP) Sensor Circuit	5I-57
J-2 Circuits with MEFI 3	5I-12	Code 23 Intake Air Temperature (IAT) Sensor Circuit	5I-60
Wiring System Diagrams	5I-14	Code 25 Intake Air Temperature (IAT) Sensor Circuit	5I-62
MEFI 1	5I-14	Code 33 Manifold Absolute Pressure (MAP) Sensor Circuit	5I-64
MEFI 3	5I-18	Code 34 Manifold Absolute Pressure (MAP) Sensor Circuit	5I-67
General Diagnostic Tests	5I-21	Code 41 Ignition Control (IC) Circuit	5I-70
On-Board Diagnostic (OBD) System Check	5I-21	Code 42 Ignition Control (IC) Circuit	5I-72
Chart A-1 No MIL or No DLC Data .	5I-23	Code 43 Knock Sensor (KS) Circuit	5I-74
Chart A-2 MIL ON Steady - Will Not Flash DTC 12	5I-25	Code 44 Knock Sensor (KS) Circuit	5I-77
Chart A-3 Engine Cranks But Will Not Run	5I-27	Code 45 Ignition Coil Driver Fault ..	5I-80
Chart A-4 Fuel System Diagnosis ..	5I-29	Code 51 Calibration Memory Failure	5I-82
Chart A-5 Fuel System Electrical Test	5I-31	Code 52 EEPROM Failure	5I-83
Chart A-6 EFI System / Ignition Relay Check	5I-33	Code 61 Fuel Pressure (FP) Circuit .	5I-84
Chart A-7 Ignition System Check ...	5I-35	Code 62 Fuel Pressure (FP) Sensor Circuit	5I-87
Chart A-8 Idle Air Control (IAC) Functional Test	5I-41		
Discrete Input Circuit Check - Non-Scan Only	5I-43		

COOLING SYSTEM

Section 6A - Seawater Cooled Models

Torque Specifications	6A-2	Seawater Pump Bearing Housing	6A-15
Tools	6A-2	Disassembly	6A-15
Special Tools	6A-2	Cleaning and Inspection	6A-16
Lubricants / Sealants / Adhesives	6A-3	Reassembly	6A-17
Specifications	6A-3	Water Circulating Pump	6A-20
Seawater Inlet Recommendations	6A-4	Removal	6A-20
Transom Mounted or Through The Hull		Cleaning and Inspection	6A-20
Seawater Pickups and Hose	6A-4	Installation	6A-20
Seacock (Seawater Inlet Valve)	6A-4	Drive Belt Tension Adjustment	6A-21
Sea Strainer	6A-4	Flushing Seawater Cooling System	6A-21
Seawater Pickups	6A-5	Thermostat	6A-21
Through The Hull Mounted	6A-5	Removal	6A-21
Transom Mounted	6A-6	Testing	6A-22
Quicksilver Sea Strainer	6A-7	Installation	6A-23
Removal	6A-7	Auxiliary Hot Water Heater	
Cleaning and Inspection	6A-9	Installation Information	6A-24
Installation	6A-9	Seawater Flow Diagrams	6A-28
Seawater Pickup Pump	6A-11	MCM 262 cid / 4.3L Alpha	6A-28
Output Test	6A-11	MCM 262 cid / 4.3L Bravo	6A-29
Disassembly	6A-13	Draining Diagrams	6A-30
Reassembly	6A-14	MCM 262 cid / 4.3L Alpha	6A-30
		MCM 262 cid / 4.3L Bravo	6A-31

Section 6B - Closed Cooled Models

Torque Specifications	6B-2	Thermostat	6B-10
Lubricants / Sealants / Adhesives	6B-2	Removal	6B-10
Specifications	6B-2	Testing	6B-11
Closed Cooling System Capacity	6B-2	Installation	6B-12
Coolant Specification	6B-2	Changing Coolant	6B-13
Thermostat	6B-2	Closed Cooling Section	6B-13
Pressure Cap Rating	6B-2	Change Intervals	6B-13
Description	6B-3	Draining Instructions	6B-13
Coolant Recommendations	6B-3	Cleaning System	6B-14
Maintaining Coolant Level	6B-3	Closed Cooling Section	6B-14
Pressure Cap Maintenance	6B-4	Seawater Section	6B-15
Heat Exchanger Repair	6B-5	Filling Closed Cooling Section	6B-16
Testing Closed Cooling System	6B-6	Auxiliary Hot Water Heater Installation	6B-18
Testing Coolant for Alkalinity	6B-6	Heat Exchanger Bracket Hardware	6B-19
Pressure Testing System	6B-6	Heat Exchanger Hose Connections	6B-20
Testing for Cylinder Head		Water Flow Diagram	6B-21
Gasket Leak	6B-7	MCM 262 cid / 4.3L Alpha	6B-21
Testing Heat Exchanger	6B-8	MCM 262 cid / 4.3L Bravo	6B-22
Testing Pressure Cap	6B-8		

EXHAUST SYSTEM

Section 7A - General

Exhaust System Requirements	7A-2
Exhaust Elbow Risers	7A-2
MCM (Sterndrive) Engines With Through The Transom Exhaust	7A-2

Section 7B - Manifolds, Elbows and Risers

Torque Specifications	7B-2	Installation	7B-6
Lubricants / Sealants / Adhesives	7B-2	Gaskets	7B-6
Exhaust Riser (Kit)	7B-2	Manifold	7B-7
Disassembly	7B-2	Sterndrive Exhaust Extension	7B-9
Cleaning and Inspection	7B-4		

Section 7C - Collectors

Torque Specifications	7C-2
Lubricants / Sealants / Adhesives	7C-2
Bullhorn Exhaust	7C-3
Shutter Replacement	7C-3
Component Replacement	7C-4

DRIVES

Section 8A - Drive Shaft

Torque Specifications	8A-2	Replacement Drive Shafts	8A-7
Tools	8A-2	Drive Shafts Modified to Shorter Lengths	8A-8
Lubricants / Sealants / Adhesives	8A-2	Installation	8A-8
Flywheel Housing / Output Shaft Housing Repair	8A-3	Bearing Support Repair	8A-10
Exploded View	8A-3	Removal	8A-10
Removal and Installation	8A-4	Disassembly	8A-10
Disassembly	8A-4	Reassembly	8A-11
Reassembly	8A-5	Installation	8A-12
Drive Shaft Repair	8A-5		
Removal	8A-5		
Repair	8A-7		

POWER STEERING SYSTEM

Section 9A - Pump And Related Components

Torque Specifications	9A-2	Testing and Repair	9A-8
Tools	9A-2	Checking Pump Fluid Level	9A-8
Special Tools	9A-2	Filling and Air Bleeding System	9A-8
Lubricants / Sealants / Adhesives	9A-2	Pump Assembly	9A-8
Precautions	9A-3	Removal	9A-8
Power Steering Pump and Components (Exploded View)	9A-3	Installation	9A-10
Serpentine Belt Routing	9A-4	Hydraulic Hoses and Fluid Cooler	9A-11
S/N 0L619083 and Below	9A-4	High Pressure Hose (Pump-to-Control Valve)	9A-11
S/N 0L619084 and Above	9A-5	Low Pressure Hose (Cooler-to-Pump)	9A-13
Serpentine Belt Adjustment	9A-6	Low Pressure Hose (Control Valve-to-Cooler)	9A-15
Removal	9A-6		
Installation	9A-6		
Important Service Information	9A-7		
Pump Pulley Replacement	9A-7		

V-6 Models Covered in This Manual

Model	Serial Number	Model Year
MCM 4.3L Alpha	0L010065	1998 and Up
MCM 4.3L Bravo	0L010262	
MCM 4.3LH Alpha	0L010045	
MCM 4.3LH Bravo	0L010044	
MCM 4.3L EFI Alpha	0L012009	
MCM 4.3L EFI Bravo	0L012054	

IMPORTANT INFORMATION

Section 1A - General Information

**1
A**

Table of Contents

Introduction	1A-2	Propeller Information	1A-5
How to Use This Manual	1A-2	Water Testing New Engines	1A-6
Page Numbering	1A-2	Boat and Engine Performance	1A-6
How to Read a Parts Manual	1A-3	Boat Bottom	1A-6
Directional References	1A-4	Marine Fouling	1A-7
Engine Rotation	1A-4	Weight Distribution	1A-8
Engine Serial Number Location	1A-5	Water in Boat	1A-9
		Elevation and Climate	1A-9

Introduction

This comprehensive overhaul and repair manual is designed as a service guide for the models previously listed. It provides specific information, including procedures for disassembly, inspection, assembly and adjustment to enable dealers and service mechanics to repair and tune these engines.

Before attempting repairs or tune-up, it is suggested that the procedure first be read through to gain knowledge of the methods and tools used and the cautions and warnings required for safety.

How to Use This Manual

This manual is divided into sections which represent major components and systems.


Some sections are further divided into parts which more fully describe the component.

Sections and section parts are listed on the "Service Manual Outline" page following "V-6 Models Covered in This Manual" page.


Page Numbering

Two number groups appear at the bottom of each page. Following is an example and description.

Page 1A-2




90-17431--4 FEBRUARY 1998



- a** - Section Number
- b** - Section Part
- c** - Page Number
- d** - Manual Part Number
- e** - Revision Number
- f** - Month Printed
- g** - Year Printed

How to Read a Parts Manual

Power Steering Pump Assembly



REF. NO.	PART NO.	SYM.	QTY.	DESCRIPTION
1	90507A12		1	PUMP ASSEMBLY–Power Steering
2	36- 95805		1	CAP
3	73873A1		1	PULLEY
4	16- 41877		1	STUD
5	57- 65607T		1	V-BELT
6	32- 806684		1	HOSE–Pressure (FITTINGS ON BOTH ENDS)
7	25- 89879		1	O-RING
8	25- 806232		1	O-RING
9	13- 35048		1	LOCKWASHER (3/8 in.)
10	61990		1	CABLE TIE

REF. NO. : Number shown next to part on exploded view


PART NO. : Mercury Part Number for ordering. If NSS (not sold separately) sometimes GM part number will be given in description column.

QTY. : The quantity that must be ordered.

DESCRIPTION : Description of part, what parts are included with a part (all indented items come with the main item above the indented parts), serial number information, and special information.

Directional References


Front of boat is bow; rear is stern. Starboard side is right side; port side is left side. In this manual, all directional references are given as they appear when viewing boat from stern looking toward bow.



72000

Engine Rotation


Engine rotation is determined by observing flywheel rotation from the rear (stern end) of the engine looking forward (toward water pump end). Propeller rotation is not necessarily the same as engine rotation. When ordering replacement engine, short blocks or parts for engine, be certain to check engine rotation. Do not rely on propeller rotation in determining engine rotation.



72001

Left Hand Rotation

Engine Serial Number Location



72975

- a - Serial Number Plate
- b - Starter Motor

Propeller Information

Refer to the “Propeller” section in appropriate Mercury MerCruiser Sterndrive Service Manual, or order publication 90-8614492, “What You Should Know About Quicksilver Propellers.”

Changing diameter, pitch or coupling of a propeller will affect engine rpm and boat performance. The blade configuration also will affect performance. Two like propellers, same pitch and diameter, from two different manufacturers also will perform differently.

It is the responsibility of the boat manufacturer and/or selling dealer to equip the boat with the correct propeller to allow the engine to operate within its specified rpm range at wide open throttle (WOT).

Because of the many variables of boat design and operation, only testing will determine the best propeller for the particular application.

To test for correct propeller, operate boat (with an average load onboard) at WOT and check rpm with an accurate tachometer. Engine rpm should be near top of the specified range so that, under heavy load, engine speed will not fall below specifications.

If engine exceeds the specified rpm, an increase in pitch and/or diameter is required.

If engine is below rated rpm, a decrease in pitch and/or diameter is required.

Normally, a change of approximately 200 rpm will be achieved for each one inch pitch change of a propeller.

CAUTION

If a propeller is installed that does not allow engine rpm to reach the specified full-throttle rpm range, the engine will “labor” and will not produce full power. Operation under this condition will cause excessive fuel consumption, engine overheating and possible piston damage (due to detonation). On the other hand, installation of a propeller, that allows engine to run above the specified rpm limit, will cause excessive wear on internal engine parts which will lead to premature engine failure.

Water Testing New Engines

Use care during the first 20 hours of operation on new Mercury MerCruiser engines or possible engine failure may occur. If a new engine has to be water-tested at full throttle before the break-in period is complete, follow this procedure.


1. Start engine and run at idle rpm until normal operating temperature is reached.
2. Run boat up on plane.
3. Advance engine rpm (in 200 rpm increments) until engine reaches its maximum rated rpm.

IMPORTANT: Do not run at maximum rpm for more than 2 minutes.

Boat and Engine Performance

Boat Bottom


For maximum speed, a boat bottom should be as flat as possible in a fore-aft direction (longitudinally) for approximately the last 5 ft (1.5 m).



72002

a - Critical Bottom Area

For best speed and minimum spray, the corner between the bottom and the transom should be sharp.



72003

a - Bottom
b - Corner
c - Transom